

# Handspray High Pressure Installation Guide



Cistern

3 way Divertor

Braided hose

Tap on wall

Dual check valve

350 KPA pressure reducer

Green washer

Mesh washer

Pipe to handspray



**Water Mark**  
AS/NZS 3718  
Cert . No 23342

This installation kit is watermarked for use only with handspray brand tap outlets models BS-01, BS-02, BS-03 and BS-04.

Should be installed by a plumber in accordance with AS/NZS 3500.1

For further information, please go to [handspray.com.au](http://handspray.com.au)