

Handspray Standard Installation Guide



W™
Water Mark
AS/NZS 3718
Cert . No 23342



Cistern

3 way Divertor

Braided hose

Tap on wall

Green washer

Mesh washer

Dual check valve

Pipe to handspray

This installation kit is watermarked for use only with handspray brand tap outlets models BS-01, BS-02, BS-03 and BS-04.

Should be installed by a plumber in accordance with AS/NZS 3500.1

For further information, please go to handspray.com.au